Philips
Spout cover

# Viva Cafe

Metal

CRP698

## To cover the foam chamber of your SENSEO® coffee machine.

## Go to the Specifications Tab to check your matching product

In the coffee spout of your SENSEO® coffee machine the coffee is collected and properly guided into your cup. This lid is meant to cover it. Detachable, so easy to clean – and when lost easily replaceable by a new one!

**Ease of using Philips spare parts**

- Renew your product with original Philips parts

PHILIPS

sense and simplicity

Spout cover
Viva Cafe Metal

CRP698/01

# Specifications

### Replaceable part

- Fits product types: HD7825/10, HD7825/11, HD7825/20, HD7825/21, HD7825/30, HD7825/31, HD7825/40, HD7825/41, HD7825/50, HD7825/51, HD7825/60, HD7825/61, HD7825/62, HD7825/70, HD7825/71, HD7825/80, HD7825/81, HD7827/50, HD7827/51, HD7827/52, HD7828/10, HD7828/11, HD7835/10, HD7835/11

# Highlights

### Easy replacement

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality and 1:1 exchange.

Issue date 2013-01-10

Version: 2.0.1

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com